

Part # CHR-SDLBRK-X

October 2008

## Saddlebrook Assembly Instructions

1. Place large end of pole into base.
2. Carefully place seat on hydraulic end of pole.
3. Sit to secure.

