


Ellen Dining Chair


Part # DC-ELLEN XXXX

19-0121

PARTS



A



x2

B



x6

C




x6

D




E

1



2



Do not over tighten.
Do not use power tools to assemble.