






Ellen Dining Chair

Part # DC-ELLEN XXXX

19-0121

PARTS**1****2**

Do not over tighten.
Do not use power tools to assemble.