
Assembly Instructions Instrucciones De Asamblea Instructions d'Assemblée

Part # LS-DARBYTB XX 20-1030



CAUTION

For indoor use only. Keep out of reach of children and animals. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas.

Use 120V~60Hz, 25 watt E26 bulb only(or LED equivalent).